

Wood Floor Care

Oiled Surfaces

1

1. Step: Preparation Before Cleaning

Vacuum floor before wet cleaning to ensure that dirt and grit is removed.

Mix 125 ml of Woca Naturel Soap in 5lt of lukewarm water.

Make a second bucket of plain water ready.

2

2. Step: General Cleaning

1. Clean the floor with the Woca Naturel Soap and water mix using a cotton cloth or a soft flat mop.
2. Make circular motions with your mop while cleaning.
3. When your mop starts to get dirty, clean it with the clean water in your second bucket. Dip your mop back into the soaped water and continue to clean your floor. You may need to wash your mop or cotton cloth after cleaning.
4. Leave surface to dry for 2 hours.



Woca Naturel Soap for Oiled Surfaces

For a more professional cleaning, please contact our firm.